



EZ1102 Ammonium Analyser (Berthelot Method)

Številka izdelka: EZ1102.XXXXXXXXXX
EUR Cena: Kontakt

Online colorimetric analysis of Ammonium in water

EZ1000 Ammonium Analysers achieve excellent precision and accuracy. At the heart of the colorimeter there is a compact photometer assembly developed especially for the EZ Series. Consumption of reagents is reduced by low volume analysis, yet high sensitivity is assured by a long optical path length. The limit of detection is in the low $\mu\text{g/L}$ range.

Results you can rely on

Smart automatic features for calibration, validation, priming and cleaning are embedded in the controller software and contribute to analytical performance, maximised uptime and negligible operator intervention. Precision micropumps dose all reagents. Sample lines and analysis vessel are cleaned with demineralised water to eliminate cross contamination between samples. Electronic and wet-chemical part of the analyser are strictly separated. A transparent door allows for instant visual inspection of the wet part.

Flexibility that meets your needs

EZ Series Ammonium Analysers come in an attractive, ergonomic mainframe with a compact footprint. All hardware is controlled by the integrated industrial panel PC. The modular build allows for the analyser to match your application and operational needs.

- The standard measuring range can be narrowed by a different calibration range or extended via internal dilution options.
- Analogue and digital output options
- Multiple stream analysis for up to 8 sample streams

There are many additional options available. Please contact Hach for more details.

Specifikacije

Alarm:	1x malfunctioning, 4x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Analogni izhodi:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Avtomatsko čiščenje:	Da
Certificiranje:	CE compliant / ETL certified
Demineralised water:	For rinsing / dilution
Digital outputs:	Optional: Modbus (TCP/IP, RS485)
Dimenzija (v x š x g):	690 mm x 465 mm x 330 mm
Earth connection:	Dry and clean earth pole with low impedance ($< 1 \text{ Ohm}$) using an earth cable of $> 2.5 \text{ mm}^2$

Garancija:	24 mesecev
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Interference :	Amino acids, hydrazine and urea. Large amounts of colour and turbidity interfere. Fats, oil, proteins, surfactants and tar.
Kakovost vzorca:	Maximum particle size 100 µm, < 0.1 g/L; Turbidity < 50 NTU
Kiveta za vzorec:	25 min (dilution + 5 min)
Material:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Meja zaznavanja:	≤ 5 µg/L
Merilna metoda:	Colorimetric measurement at 630 nm based on standard method APHA 3500-NH3 (Berthelot)
Merilno območje:	0.025 - 1 mg/L NH ₄
	Optional:
	0.005 - 0.1 mg/L NH ₄
	0.01 - 0.25 mg/L NH ₄
	0.01 - 0.5 mg/L NH ₄
	0.2 - 4 mg/L NH ₄ (with internal dilution)
	0.4 - 8 mg/L NH ₄ (with internal dilution)
	2.5 - 100 mg/L NH ₄ (with internal dilution)
Moč:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Model:	EZ1102
Način premora:	100 - 240 VAC, 50/60 Hz
Odvod:	Atmospheric pressure, vented, min. Ø 32 mm
Parameter:	Ammonium
Precision:	Better than 2% full scale range for standard test solutions
Pretok vzorca:	100 - 300 mL/min
Razred zaščite:	Protection class: Analyser cabinet: IP44 / Panel PC: IP65
Reagent Requirements:	Keep between 10 - 30 °C
Št. vzorca:	1, 2, 4, or 8
Temperatura okolja:	10 - 30 °C ± 4 °C deviation at 5 - 95% relative humidity (non-condensing)
Temperatura vzorca:	10 - 30 °C
Teža:	25 kg
Umeritev:	Automatic, 2-point; frequency freely programmable
Validation:	Automatic; frequency freely programmable
Vsebina paketa:	EZ1102 Ammonium (Berthelot Method) Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 2 x empty 2.5L Glass Reagent Containers with Fittings (for Reagent A & Reagent B Solution)
Vzorec: tlak:	By external overflow vessel

Vsebina paketa

EZ1102 Ammonium (Berthelot Method) Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets and 2 x empty 2.5L Glass Reagent Containers with Fittings (for Reagent A & Reagent B Solution)